

Taking Care of Your Marco Polo Watch

In the sea: always rinse your watch with warm water afterwards., Shocks: whether thermal or other, avoid them., Crown: press it in carefully to ensure that no water enters the mechanism., Cleaning: for cases use a toothbrush with soapy water and a soft cloth for drying. Avoid getting the leather strap wet as water will shorten the life of the strap. Chemical products: avoid direct contact with solvents, detergents, perfumes, cosmetic products etc., since they may damage the strap, the case or the gaskets.

Marco Polo Warranty

Marco Polo watches are guaranteed for a period of one year from the date of purchase. This guarantee, applies only to Marco Polo watches purchased directly from Marco Polo or at an approved dealer and whose warranty card has been filled in by the dealer. Not included in the manufacturer's guarantee:

- The battery, glass, non-metallic bracelet.
- Damage due to an accident, normal wear and tear, negligence, poor treatment or attempts to repair by an agent or his representatives, not approved by Marco Polo.
- Loss or theft.
- All damage subsequently directly or indirectly attributable to any inappropriate usage, lack of precision, malfunction or lack of conformity of the watch.

In case of defects covered by the guarantee, your watch will be repaired or replaced free of charge at the sole discretion of Marco Polo Watch Company. For defects covered by the guarantee, we recommend that you send your Marco Polo watch and warranty card by registered mail, carefully packed, to:

Customer Service
SAPG
1775 Broadway, Suite 617
New York, New York 10019

model:

purchase date:

purchased from:



MARCO POLO
watches

Instructions and Warranty

MARCO POLO WATCH CO.
A division of Suisse American Products Group
1775 Broadway Suite 617
New York, New York 10019



Marco Polo World Time Watch Functions

A - This crown is used to rotate the outer city bezel of the watch. Turning the crown clockwise will turn the dial counter-clockwise.

B,C,D - This crown has three positions. Position **B** is the position that the crown should be in for normal wear. Position **C** will adjust the fourth (GMT) hand of the watch when turned clockwise and will move the date forward when rotated counter-clockwise. Position **D** will adjust the hour and minute hands.

E - This crown is used to rotate the inner 24 hour bezel of the watch. Turning the crown clockwise will turn the dial counter-clockwise.

F - Outer city bezel shows representative cities for 24 time zones.

G - 24 hour dial

H - Fourth (GMT) hand

I - Date

Marco Polo World Time Watch Instructions

The Marco Polo World Time watch has three crowns. Each crown has a specific function as shown above. To set your watch for normal use, simply pull crown **B** out to position **D**, this will allow you to set the time. At position **C** you may change the date and the fourth (GMT) hand.

To use the world time function of your watch - 1. Set your watch to the correct time in your time zone. 2. Twist crown **A** until the city within your time zone is aligned with the hour hand. 3. Twist crown **E** until the inner 24 hour dial is also aligned to the current time in your city. (The hour hand, 24 hour inner dial and city dial should all be in alignment.) Now simply look at the rest of the dial and the other cities will be aligned with the current time as indicated by the 24 hour inner dial. Pull crown to position **C** and turn clockwise until the fourth hand points to the time matching the hours on the 24 hour inner dial and coincident to the name of the city of your choice. To set the date, pull crown to position **C** and turn counter-clockwise.

Thank you for purchasing a Marco Polo watch. Your watch is designed to last you many years with the proper care. We are dedicated to producing unique functional watches that offer exceptional quality at outstanding prices. If you have any questions about your watch, please look to our website at www.marcopolowatches.com for many frequently asked questions. You also may e-mail us at customerservice@marcopolowatches.com or call our customer service number at 1-800-268-2408.

F**A****B C D****E**

Marco Polo Chronograph Watch Functions

A - This crown is used to start and stop Chronograph functions.

B,C,D - This crown has three positions. Position **B** is the position that the crown should be in for normal wear. Position **C** will adjust the date forward when rotated counter-clockwise. Position **D** will adjust the hour and minute hands.

E - This crown is used to setback the Chronograph functions.

F - This crown is used to adjust the outer minute ring. You may use this ring to track time to quickly track time that has passed by placing the arrow where the current minute hand is located.

Marco Polo Chronograph Watch Instructions

To use simple chronograph functions, simply press **A** to start and stop the timer.

Press **E** to reset. If you need to completely reset the chronograph dials, you must

“zero” the hands. To zero the sixty second counter hand, place crown in position

C and depress **E**. To zero the thirty minute hand, place crown in position **D** and

depress **A**. To zero the 1/10th second hand place crown in position **C** and depress **A**.

Thank you for purchasing a Marco Polo watch. Your watch is designed to last you many years with the proper care. We are dedicated to producing unique functional watches that offer exceptional quality at outstanding prices. If you have any questions about your watch, please look to our website at www.marcopolowatches.com for many frequently asked questions. You also may e-mail us at customerservice@marcopolowatches.com or call our customer service number at 1-800-268-2408.



Marco Polo Quartz GMT World Time Watch Functions

A - This crown is used to rotate the outer city bezel of the watch. Turning the crown clockwise will turn the dial counter-clockwise.

B, C, D - This crown has three positions. Position **B** is the position that the crown should be in for normal wear. Position **C** will adjust the fourth (GMT) hand of the watch when turned clockwise and will move the date forward when rotated counter-clockwise. Position **D** will adjust the hour and minute hands.

E - Fourth (GMT) hand

F - 24 hour dial

G - Outer city bezel shows representative cities for 24 time zones.

H - Date

Marco Polo World Time Watch Instructions

The Marco Polo World Time watch has two crowns. Each crown has a specific function as shown above. To set your watch for normal use, simply pull crown **B** out to position **D**, this will allow you to set the time. At position **C** you may change the date and the fourth (GMT) hand.

To use the world time function of your watch - 1. Set your watch to the correct time in your time zone. 2. Twist crown **A** until the city within your time zone is aligned with the hour hand. Now simply look at the rest of the dial and the other cities will be aligned with the current time as indicated by the 24 hour inner dial. Pull crown to position **C** and turn clockwise until the fourth hand points to the time matching the hours on the 24 hour inner dial and coincident to the name of the city of your choice. To set the date, pull crown to position **C** and turn counter-clockwise.

Thank you for purchasing a Marco Polo watch. Your watch is designed to last you many years with the proper care. We are dedicated to producing unique functional watches that offer exceptional quality at outstanding prices. If you have any questions about your watch, please look to our website at www.marcopolowatches.com for many frequently asked questions. You also may e-mail us at customerservice@marcopolowatches.com or call our customer service number at 1-800-268-2408.



Marco Polo 17 Jewel World Time Watch Functions

A - This crown is used to rotate the outer city bezel of the watch. Turning the crown clockwise will turn the dial counter-clockwise.

B,C - This crown has two positions. Position **B** is the position that the crown should be in for normal wear. Rotating this pusher in this position will power the watch. Position **C** will adjust the hour and minute hands.

D - 24 hour dial

E - Outer city bezel shows representative cities for 24 time zones.

Marco Polo World Time Watch Instructions

The Marco Polo World Time watch has two crowns. Each crown has a specific function as shown above. To set your watch for normal use, simply pull crown **B** out to position **C**, this will allow you to set the time.

To use the world time function of your watch - 1. Set your watch to the correct time in your time zone. 2. Twist crown **A** until the city within your time zone is aligned with the hour hand. Now simply look at the rest of the dial and the other cities will be aligned with the current time as indicated by the 24 hour inner dial.

Thank you for purchasing a Marco Polo watch. Your watch is designed to last you many years with the proper care. We are dedicated to producing unique functional watches that offer exceptional quality at outstanding prices. If you have any questions about your watch, please look to our website at www.marcopolowatches.com for many frequently asked questions. You also may e-mail us at customerservice@marcopolowatches.com or call our customer service number at 1-800-268-2408.



Marco Polo Dual Time Watch Functions

- A** - This crown is used to set the D dial. Pull out to set the time (hours and minutes). The crown should be pushed in fully for normal wear.
- B** - This crown is used to set the C dial. Pull out to set the time (hours and minutes). The crown should be pushed in fully for normal wear.
- C** - Main dial for current time-zone
- D** - Second dial for second time-zone

Marco Polo Dual Time Watch Instructions

The Marco Polo World Time watch has two crowns. Each crown has a specific function as shown above. To set your watch for normal use, simply pull crowns **A** or **B** out slightly, this will allow you to set the time.

To use the dual-time function of your watch - 1. Set dial **C** to the correct time in your time zone. 2. Set dial **D** to second time zone. Both dials will keep the correct time in each time-zone until changed.

Thank you for purchasing a Marco Polo watch. Your watch is designed to last you many years with the proper care. We are dedicated to producing unique functional watches that offer exceptional quality at outstanding prices. If you have any questions about your watch, please look to our website at www.marcopolowatches.com for many frequently asked questions. You also may e-mail us at customerservice@marcopolowatches.com or call our customer service number at 1-800-268-2408.